

MTU  
MTU-A

# USB



# Connectivity

Since most computer manufacturers have abandoned parallel ports in favour of USB ports, Phoenix has developed a USB interface cable and supporting driver to connect a PC to our MT and AMT receivers.

## USB2PAR cable

- No adapters required.
- Direct connection from PC to MTU or MTU-A.



Phoenix USB2PAR cable  
(Part number 8103)

## Software and Drivers

**PC:** All upgrades require Winhost for MTU ver. 37 or later or Winhost for MTU-AMT ver. 15 or later. The Phoenix USB driver is included with the Winhost installation. Registered customers can download the software from our Web site.

For pricing and availability, please contact your Phoenix Geophysics sales representative.

© 2011 Phoenix Geophysics Limited



## PHOENIX Geophysics Limited

3781 Victoria Park Avenue, Unit 3

Toronto, ON, Canada M1W 3K5

[www.phoenix-geophysics.com](http://www.phoenix-geophysics.com)

☎: +1 (416) 491-7340

☎: +1 (416) 491-7378

✉: [mail@phoenix-geophysics.com](mailto:mail@phoenix-geophysics.com)

*Specification version 2.0, March 2011. Subject to change without notice.*